





Automatic false start monitoring system for races

Operating mode




Installation for sprints/street




Installation for sprints/street



cabel
reflector
photo sensor
scratch line



Installation for racetrack 400/800m




Installation for racetrack 400m



Optical indication


for riders



lamp

photo sensor

for starter




cabel

lamp

Starting position correct

view of the rider




lamp isn't
glowing

view of the starter




Starting position false


view of the rider



view of the starter



starting correct, no alert



false start, optical and acoustical alert

